
Register No:	99220040570
Name:	K.Hanumaan
Class/Section:	8501 A/S06
Ex.No:	10
Name of the Experiment	Capture and Analyse TCP and IP packets
Google Drive link of the packet tracer file (give view permission):	https://drive.google.com/drive/folders/1qvnsMZNaThgj8Ps7meXTnRsGRaXqe0hl?usp=drive_link

1. Visit any one website by opening a browser and fill your machine details.


Parameter	Value
Your Machine IP Address.	172.16.103.254
Your Machine MAC Address	14-D4-24-17-5E-9B
Default Gateway address	10.2.0.1
Website URL	https://www.slideshare.net/
Website IP Address	20.72.205.209

2. Fill the following IP packet details:

Field Name	Field Length (no of bits)	Field value
Destination MAC address	48 bits	14:d4:24:17:5e:9b
Source MAC address	48 bits	c8:4f:86:fc:00:10
Destination IP address	32 bits	10.2.16.28
Source IP Address	32 bits	20.72.205.209
Destination TCP port	16 bits	60619
Source TCP port	16 bits	443




3. Fill the details as per the IP frame format .(highlight the details for each of the output and paste screenshot)




Field Name	Field Value (# of bits)	Field Value (Either Binary or Hex Value)
Version	4 bits	4 (IPv4)
Header Length	4 bits	20 bytes (5 in 32 – bit words)
Type of service	8 bits	0x00
Datagram Length	16 bits	40 (0x0028 in hex)
16 bit Identifier	16 bits	0x604F (24655 in decimal)
Flags	3 bits	0x2 (Don't Fragment Set)
13-bit Fragment offset	13 bits	0 (No fragmentation)
Time-to-live	8 bits	112
Upper layer protocol	8 bits	TCP (6)
Header Checksum	16 bits	0xAE48
32 bit Source Address	32 bits	20.72.205.209
32 bit destination address	32 bits	10.2.16.28
Options (if any)	Variable	None
Date	Variable	None

Paste the screenshot and highlight the above details:




TCP Header Format:



TCP Header.

Field Name	Field Value (# of bits)	Field Value (Either Binary or Hex Value)	
Source Port	16 bits	443 (0x01BB in hex)	
Destination Port	16 bits	60619 (0xECDB in hex)	
Sequence No.	32 bits	1 (0x00000001 in hex)	
Acknowledgement No	32 bits	1 (0x00000001 in hex)	
Header Length	4 bits	20 bytes (5 in 32-bit words)	
FLAGS (URG,PSH,ACK,RST,SYN,FIN)	6 bits	0x011 (FIN, ACK)	
Receive Window Size	16 bits	49150 (0xC01E in hex)	
Checksum	16 bits	0x5B7B	
Urgent Pointer	16 bits	0x0000	
Options	Variable	None	
Data	Variable	None	

Paste the screenshot and highlight the above details:



Rubrics for Wireshark labs:

Rubrics	Excellent	Fair	Poor	Marks
Understanding (2)	Understand the Concept very well. (2)	Understand the Concept (1)	Poor Understand the Concept (0)	
Usage of filters (3)	Identified and applied the filter correctly (3)	Identified the filter, but not applied correctly (2-1)	Couldn't identify and apply the filter. Just captured the packets (1)	
Attach relevant Screenshots (3)	clearly Highlighted the answers and attached the screenshots (3)	attached the screenshots, but not highlighted. (2-1)	Did not attach the screenshots (0)	
On time Submission (2)	Early or on time submission (2)	Submitted after deadline (1)	Did not Submit (0)	
			Total	

Result: Thus the Capture and analyse TCP and IP Packets has been implemented and successfully verified.